

- NOTES:

 1. A SAW SHALL BE USED TO CUT ASPHALT OR CONCRETE FULL DEPTH PRIOR TO OPENING THE DITCH IN ORDER TO INSURE A NEAT STRAUGHT EDGE. BROKEN OR SPALLED EDGES WILL BE RE—SAWED FULL DEPTH BETWEEN JOINTS OR FULL LENGTH OF CUT.
- 2. CTB CEMENT TREATED BASE (CONTAINS AGGREGATE) CTS — CEMENT TREATED SAND BOTH MATERIALS SHALL BE MECHANICALLY TAMPED.

EXISTING STREET BACKFILL & REPAIR

